MOUNTING INSTRUCTIONS



A-12099 **TEMPERED GLASS HARD DOORS KIT** FOR JDX MY14 COZY CABS A-12098

Before you begin, read these instructions and identify all components. Please retain these instructions for future reference and parts ordering information.

Note: Cab should be installed prior to installing doors kit. Refer to kit components and Figure 1 for general layout.


Kit Components:		OT) (DADTA	DECORIDEION
rate Components:	ITEM	QTY	PART No.	DESCRIPTION
	1	1	4-16059	DOOR ASSEMBLY, LH
	2	1	4-16060	DOOR ASSEMBLY, RH
	3	1	4-16070	HARDWARE KIT, CONSISTS OF ITEMS A-E
	Α	2	3-11821	BALL STUD
	В	4	3-15971	BRASS WASHER FOR HINGE
	С	2	3-18070	JAM NUT, M10

3-19563

D

Ε

1




STRIKER STUD, M10 X 13MM LG

Figure 1 (General Layout)

MOUNTING INSTRUCTIONS


Mounting the doors (If not already installed from factory);


- 1. Place brass washer (B) onto each door mount hinge pin.
- 2. Place LH door assembly (1) onto LH door mount pins.
- 3. Install ball stud (A) onto each side of cab header.
- 4. Connect gas spring to cab header panel ball stud (A) using gas spring already installed on door.
- 5. Install 10mm striker stud (D) onto front LH cab frame striker mount location. Secure stud using a 10mm jam nut (C).
- 6. Locate door handle keys (Supplied tied to inside door handle from factory) and set aside.
- 7. The latch is a 2-position rotary latch. Close and open door. The correct latch position would be the 2nd (Click) inward position, when closed. Adjust striker stud (D) and glass door hinges as needed to get proper alignment.
- 8. Repeat steps 2 through 7 on RH side of cab using RH components.





PO BOX 70, 1715 S. Sibley Avenue, Litchfield, MN 55355-0070 Ph: (320) 693-3221 Fax: (320) 693-4833 www.800cabline.com





OBJECT:4-16059

