

A-11638 EZ CAB HEADLINER KIT WITH FUSE BLOCK, DOME LIGHT AND WIRE HARNESSES

Note: Do not exceed the machine's available alternator capacity. If you do not know how much current is available, contact your dealer or manufacturer of this machine, prior to installing this kit or options that require additional power.

Kit Components:

ITEM	QTY	PART NO.	DESCRIPTION
1	1	4-15331	HEADLINER ASSEMBLY
2	1	05-10804	MOUNTING INSTRUCTIONS FOR A-11638
3	1	3-19280	MAIN WIRE HARNESS
4	1	3-19281	SWITCHES TO ACCESSORIES WIRE HARNESS
5	1	3-19282	FUSE BLOCK TO SWITCHES WIRE HARNESS

Note: If optional accessories such as radio or ventilation fans are to be installed, do so now, prior to securing headliner into cab. Refer to mounting instructions supplied in those kits.

Installing Main Wire Harnesses:

- 1. Place headliner inside allowing it to hang from cab frame and rear flanges. See figure 1.
- 2. Route fuse block end of main power feed wire harness 3-19280 from the engine's battery area, up the inside left front cab frame tube.
- 3. Connect red wire with 1/4" terminal ring to the headliner main fuse block terminal stud.
- 4. Connect black wire with ¼" terminal ring to a ¼" grounding stud that secures fuse block to headliner.
- 5. Locate control-engine running wire (Power to wire when tractor's ignition key is turned "On"). Using the blue Tee-Tap terminal splice, place Tee-Tap over wire and secure to blue wire from harness with male terminal connector. This connection will energize the relay to allow power up to the headliner fuse block.
- **6.** Verify that the battery end of main wire harness is long enough to reach battery. Some installers may elect to connect to starter area instead. **Do not connect battery at this time.**

Note: If no additional accessories are installed, skip steps 7 and 8. Place and secure wire harnesses inside of headliner in case accessories are to be added at a future time.

- 7. Refer to drawing 3-19282 for connecting wire harness from fuse block to switches.
- 8. Refer to drawing 3-19281 for connecting wire harness from switches to accessories.
- 9. Once accessories have been installed, connect main wire harness to battery.
- 10. Turn (Key) power on and check operation of all accessories.
- 11. Turn (Key) power off.

Headliner Installation:

- 12. If roof is already installed, remove the (4) front 5/16" x 2.50" long button head bolts that secures the roof to each side frame on as shown in Figure 2.
- 13. Tip-rotate headliner upward to mounting location as shown in Figure 1.
- 14. (Re)-Install the (4) 5/16" x 2.50" long button head bolts as shown in Figure 2.
- 15. Turn power (Key) on and verify that all accessories work properly.






Figure 1




Manufactured by:



BOX 70 • LITCHFIELD, MINNESOTA 55355-0070 (320) 693-3221 Fax: (320) 693-7252 www.800cabline.com






DRAWN: CAD DATE:

01-28-09

NAME:CAD2 OBJECT:3-19280 DATE:28-Jan-09 11:28:



TERMINAL LEGEND

ID No.	QTY	CP P/N	DESCRIPTION			
	16	3-10670	TERMINAL BLADE FEMALE 1/4" INSUL 14-16 GA			
	I	3-11434	TERMINAL EYE 1/4" BLUE 14-16 GA			
	4		TERMINAL BUTT SPLICE BLUE 14-16GA			
		3-11433	TERMINAL EYE No.10 BLUE 14-16GA Page 5 of 6			

THIS DOCUMENT CONTAINS CONFIDENTIAL INFORMATION AND IS THE PROPERTY OF CUSTOM PRODUCTS OF LITCHFIELD, INC. AND MAY NOT BE COPIED, REPRODUCED OR DISCLOSED IN ANY MATTER WITHOUT EXPRESSED WRITTEN CONSENT FROM CUSTOM PRODUCTS OF LITCHFIELD, INC.

94"

BLACK

| 4

REAR LIGHT GROUND

NOT BE COFFED, REPRODUCED ON DISCLOSED IN ANT MATTER WITHOUT EXPRESSED WATTEN CONSENT PROMICES OF ETTERFIELD, THE.											
TOLERANCES UNLESS NOTED	CUSTOMER NAME & MOD NO: EZ CABS	MATL SPEC:									
OTHERWISE	CUSTOM PRODUCTS 1715 SOUTH SIBLEY A										
.X ± .09	<i>™LE</i>	DRWG SIZE	Drwg No.		REV LEVEL						
.XX ± .06 .XXX ± .03 HOLE SIZE +.015/010 ANGLE ± .5°	WIRE HARNESS HEADLINER (SWITCHES TO ACCESSORIES)	C	3	-19281	А						
ANOLL 1.3	(0.1.1.01120) 0 71002000111207	DRAWN: (CAD DATE:	01-28-09							

