

COZY CABS

CANOPY OPTION

A-10966

to fit

TORO GROUNDSMASTER 580D

2-POST ROPS

PLEASE COMPLETELY REVIEW INSTRUCTIONS BEFORE INSTALLING CANOPY.

If you have any questions or comments please call 1-800-222-5438 and ask for technical assistance with Toro 580 Series.

INSTALLATION OF CANOPY

- A. Set the canopy on the roll bar and center.
- B. Secure the canopy by aligning the pipe spacers supplied with the holes and bolting with the four 3/8" x 4" bolts, flat washers and nylock nuts as shown in Figure No. 1.



Figure 1

REPLACEMENT PARTS TORO 580-D GROUNDSMASTER CANOPY OPTION

<u>ITEM</u>	<u>QTY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
	1	A-10966	Canopy Option Complete
1	1	2-14375	Canopy Weldment
2	1	1-35201	Canopy Insulation
3	4	1-30735	Bolt Spacer Tube
4	8	3-10086	3/8" Flat Washer
5	4	3-10396	3/8"- 16 NC x 4 Bolt
6	4	3-10073	3/8"- 16 Nylock Nut
7*	1'8"	3-10777	Small Pinchweld
8	3	3-10721	3/8" Hole Plug
9	1	05-10269	Instruction Manual

* This quantity represents the total length of this part used on this assembly. Must be purchased by the foot and cut to fit.