



A-12008

LOWER REAR SLIDER WINDOW KIT

Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these instructions for future reference and parts ordering information (**Figure 1**).

Kit Components:	ITEM	QTY	DESCRIPTION	PART NO.
	1	1	REAR WINDOW SLIDER	3-20012
	2	1	WINDOW RUBBER, 1/8 x 1/4	3-16669
	3	1	WINDOW RUBBER TOOL	3-11661




Figure 1

Rear Slider Window Installation (See Figure 1):

1. Rear roof bolts may be removed for ease of installation. Remove factory installed lower rear stationary window using a screw driver and window rubber tool (Item 3).
2. Remove stationary window rubber from window opening.
3. Place new window rubber (Item 2) into window opening, from outside of cab.
4. Place new slider window (Item 1) into window rubber from outside of cab. Lock handles to be on inside. Zip window rubber closed using window rubber tool (Item 3).a



PO BOX 70, 1715 S. Sibley Avenue, Litchfield, MN 55355-0070
Ph: (320) 693-3221 Fax: (320) 693-7252
www.800cabline.com

05-11315
June 26, 2012